



America's Accent Upholstery Source Since 1932

UPHOLSTERED BEDS—ASSEMBLY INSTRUCTIONS

TOOLS NEEDED:

Flat head screwdriver

Phillips head screwdriver or electric driver

PARTS INCLUDED:

1-Headboard

2-Upholstered Side Rails

1-Foot rail or Footboard

8-2 ½" Wood Screws

1-Box of Metal Bed Slats or wood slats with Instructions

ASSEMBLY INSTRUCTIONS:

- 1-Stand headboard up against wall where it will be placed.
- 2-Match "A" bracket on headboard to "A" end bracket of side rail, slide bracket together and tighten screw.
- 3-Match "B" bracket on headboard to "B" end bracket of side rail, slide bracket together and tighten screw.
- 4-Hold foot rail or footboard at end of rails and attach either side as above and then repeat on opposite side.
- 5-Using the 2 ½" wood screws attach 2 screws through each corner post into side rail for additional support.
- 6-Uncarton other cardboard box with center metal supports and follow instructions for installation of mattress supports.

COX MFG. CO., INC.
220 10TH ST. SW
HICKORY,
NORTH CAROLINA
28602

PHONE
828.397.4123

FAX
828.397.4163

INTERNET
www.coxmfg.com