



COX MANUFACTURING CO., INC.  
220 10<sup>TH</sup> St SW  
HICKORY, NC 28602

www.coxmfg.com  
info@coxmfg.com  
P: 828-397-4123  
F: 828-397-4163

## **ASSEMBLY INSTRUCTIONS FOR ATTACHMENT**

### **OF COX MFG. HEADBOARDS TO BED FRAMES:**

HARDWARE INCLUDED: (4) 1 3/4" X 1/4" BOLTS  
(4) 1/4" WING NUTS  
(4) 1/4" WASHERS

HOLES:

- \* Pre-drilled holes are standard on all sizes of headboards.
- \* On selected styles with upholstered legs, the predrilled holes are covered with fabric.

- (1) Locate the pre-drilled holes as shown on reverse side of this page.
- (2) Before puncturing holes, check your frame alignment with the pre-drilled holes. If holes do not align with the bed frame, new holes must be drilled.
- (3) After proper alignment, puncture the holes and place one bolt through each hole (two per leg) from the backside of the headboard, extending through the bed frame while securing with one washer and one wing nut on each bolt. Tighten securely.

Note: Because of variation in bed frames, there may be space between the floor and bottom of the headboard legs after attachment.

# HEADBOARDS

(DRAWINGS NOT TO SCALE/ HOLE LOCATION SAME ON BOTH SIDES)

